

# IMPORTANT NOTICE

When you install your Mini-Disk Drives, be SURE the drives are at least six inches (6") from the left side of the Video Display. If possible, place the drives on the other side of the Display.

## WHY?

There is a magnetic field near the bottom left of the Display, produced by a transformer inside the case. This magnetic field can cause disk errors and even erase data from your diskettes. So keep the drives (and your diskettes) at least 6" away from this side of the Display!

## HINTS

If you do place the Disk Drives on the right-hand side of the Display, your installation will be a little different from that in the Mini-Disk Operation Chapter of the TRSDOS Manual.

Just to be sure you get things right, it would be a good idea to connect the Drives exactly as described on pages 2-3 and 2-4, and THEN move the drives to the other side of the Display.

With this arrangement, your "Drive Zero" will now be the physically farthest from the Expansion Interface. However, it will still be connected to the first connector on the cable.

Thank you,

Radio Shack  
Fort Worth, Texas